

Following guidelines must be followed when an exhaust thermometer are to be mounted in an adjustable pocket.

The thread connection must be well greased with a heat resistant grease before mounting.

The thermometer are placed in the pocket so that the bottom of the stem reaches the bottom of the pocket.

Hereafter the thermometer are pulled back 2-3 mm and the nut are tightened by hand.

Use a tough-wrench to fasten the nut .

The needed torque must be between 100 -110 Nm to be sure that the cutting ring are fixed to the stem.

